


Tanglewood[®]

Proudly Powered by ENYA




SP1

Quick Start Guide

The Controls

- Press & Hold to turn the system on/off
- Press to switch between four saved tone effects
- Turn to control effect volume
- Create & adjust effects in the Enya APP



The ENYA MUSIC APP

Dial in your own preset



Master



EQ




Effects



Enya Music

Connect your SP1 to the ENYA MUSIC App to discover more features. Please download it from App Store or Google Play.

Connections



① 1/4 output jack

To external amps or PA systems


② Reset button

In case of a system crash or malfunction, the system can be reset with the reset button

③ Type-C port

Charging, system update, digital output

Type-C Charging




- Indicator Light

The indicator light flashes when the battery is being charged.

The indicator light remains on after a full charge

The red light flashes when the battery runs low



5v ●
Type-c
Charging Port


Bluetooth

Bluetooth / Power Button

- Quick double-click to enable Bluetooth Music Mode
(success with double flash)
- Connect ENYA SP1 to a smart device
- To turn off Bluetooth, make another quick double-click
(success with double flash in red)

- To access effect & tone adjustment, please download the Enya APP and connect your ENYA SP1 in the APP. Please make sure your smart device's Bluetooth is on during using.

- The APP connection (with ENYA SP1) and Bluetooth music mode can be both performed simultaneously without additional operation.





Visit the Tanglewood website for more information &
links to download the Enya App

