





KNA PICKUPS

**VC-1 CELLO PICKUP**



**INSTALLATION GUIDE**





Remove the pickup and other materials from the box.

The VC-1 is designed to fit any cello bridge. Some bridge slot openings will need to be widened slightly. We recommend 200 grit sandpaper, folding the paper appropriately to make it sturdy. If possible, use a thin piece of plastic or metal plate between the sandpaper. This will help while sanding and keep the sanded surface flat, which is important. Before you start sanding, use appropriately cut cardboard placed around the bridge to protect the varnish of the instrument. Widen the slot slowly, stopping frequently to try attaching the pickup sensor.



This will avoid making the slot too wide.





If the slot is wider than the sensor use the additional provided shims. Line up the necessary number of shims along with the sensor and slide them in the slot under the 1st (A) string. The sensor will operate equally well from either side of the bridge. We recommend installing the sensor on the right side of the bridge (A string side). Some players prefer to install the sensor on the left side (C string side).



The sensor should be facing down with the flat side of the lead cable. Hold the bridge with one hand so it does not move while installing the sensor. The sensor should fit tightly but install without force. It should not move while playing or even shaking the cello, but not too tight where the sensor or bridge can be damaged or broken.



Unroll the Velcro band and rest the jack housing on the front surface of the tailpiece.



Wrap the Velcro strap around the tailpiece and tighten to secure the jack housing in place.

With the volume of your amplifier set to zero, plug one end of a high-quality instrument cable into your pickup and the other into your favorite direct box, preamp or acoustic amplifier.

Always hold the jack while plugging and unplugging the cable.

You are now ready to enjoy your new pickup!